

Volvo

System

Resetting the Service Reminder Lamp on instrument cluster.

Title

How to reset the SRL on S80 and S/V70 1999-2001

Volvo S80

- -Ignition switch in position I (radio position).
- -Press and hold trip button on the instrument cluster.
- -Put ignition switch in position II.
- -Continue to hold trip button for 10 sec.
- -SRL lamp should start to flash.
- -Within 5 sec release trip button.
- -Sound/beep will confirm a successful SRL reset.

Volvo S/V70

- -Ignition off.
- -Press and hold trip button on the instrument cluster.
- -Switch ignition on.
- -Continue to hold trip button 10 sec.
- -SRL lamp should start to flash.
- -Within 5 sec release the trip button no later than 4 sec after the lamp started to flash.

Technical Support
Autodiagnos

The information in this data sheet is subject to change without notice. Autodiagnos AB shall not be liable for technical or editorial errors or omissions contained herein; nor for incidental or consequential damages resulting from the furnishing, performance, or use of this material.
